



TAO9972

Festive Branch Path Lights


Operating Instructions

**BEFORE USING THIS PRODUCT:
PLEASE READ, UNDERSTAND AND FOLLOW
THESE INSTRUCTIONS.**

Contents

8 x Festive Branch Lights on 9.2 mtr string
including power supply

8 x Stakes
Instructions




BATTERY INSTRUCTIONS

- This item requires 3 AA batteries (not included)
- It is recommended to use our rechargeable AA NiMH batteries (Ref: TAO9024)
- Do not mix old and new batteries
- Do not mix alkaline, standard (carbon-zinc) or rechargeable batteries
- Please replace only with type AA batteries
- Always replace the whole set of batteries at one time, taking care not to mix old and new ones, or batteries of different types
- Clean the battery contacts and also those of the device prior to battery installation
- Ensure the batteries are installed correctly with regard to polarity (+ and -)
- Remove batteries from equipment which is not used for a period of time
- Do not dispose of batteries in a fire. Batteries may leak or explode

CAUTION: Bulbs are non-replaceable, do not attempt to replace lamps or modify string or the product as this will void the warranty.

INSTALLING OR REPLACING BATTERIES


1. Open the battery compartment cover by opening the two locking latches (a).
2. Install three new AA size batteries (not included), observing the correct polarity (+/-) as indicated, and then close the battery compartment, insuring the locking latches are closed securely.



OPERATING INSTRUCTIONS

When removing from the box for the first time gently bend and shape the branches to your required style.

1. Press the power button (b) to turn on the product. Lights always start in function 1 - Combination. After selecting the desired function the lights will continue for 6 hours, then automatically stop for 18 hours.
2. Press the power button again to change the lights to the next function. Functions available are: Combination, Waves, Sequence, Slow Glow, Flashing, Slow Fade, Twinkle and Constant.
3. After the 8th function (Constant), press the power button again to set the lights to OFF.



4. When packing away, gently bend the branches back to a uniform position to fit safely and securely inside box.

Note: This equipment has been tested and found to comply with the limits for Class B digital device, pursuant to part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with

the instructions, may cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try and correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Consult the dealer or an experienced Radio/TV technician for help.

**DECORATIVE USE ONLY, NOT A TOY
FOR INDOOR AND OUTDOOR USE**

Disposal:

Electrical equipment and batteries should never be disposed of with general household waste. They must be separately collected for proper disposal.

The  symbol on the product reminds you of the need to

dispose of the product correctly at the end of its life. Please dispose of at your local recycling centre.

Warranty:

This product is guaranteed by Accessory Outlet for a period of 1 year from the date of purchase under a Limited Warranty Agreement. During this period if there is a defect due to faulty materials or workmanship, the retailer from whom you purchased it will replace it with the same or a similar model on production of your purchase receipt or proof of purchase. This guarantee does not cover defects arising from accidental damage, misuse or wear and tear, and is available only to the original purchaser of the product. This does not affect your statutory rights.



Contact:

Valiant is a trading name of The Accessory Outlet Ltd.

Solution House, Sandon Road,
Therfield, Hertfordshire, SG8 9RE

The helpline is a one-to-one service available between the hours of:

Monday to Friday: 8.30am - 4.30pm

Tel: +44 (0) 1763 284181

Email: contact@simplyvaliant.co.uk

Website: www.simplyvaliant.co.uk

To ensure that your call is handled quickly and efficiently, please ensure you have the model number (TAO9972) and any other relevant information regarding your product to hand at the time of your call. Please retain these instructions for future use.

